



Instructions

8890MA NOVA Arm: switch clamp mount to bolt through

- 1) Small in-set Allen head screw that needs to be loosened. Allen wrench included.
- 2) Bolt to be removed - it will release the bottom of the Clamp.
- 3) Pull the main support from the clamp bracket.



The rubber cork will still be installed on the bottom of the support, but it will need to be trimmed.

Once the location for the support is determined, a 3/8" hole is needed.

The bolt through hardware consists of :

(1) 3/8" x 2 1/2" bolt, (1) 2" round washer and (1) NuLock nut.

The Bolt is dropped into the mounting bracket where the factory bolt was removed. It will go through the 3/8" hole drilled into the work surface. Put on the washer, then the nut to secure the support from underneath the work surface

The body of the arm is then put back into the bracket and the small Allen screw is tightened.

For further information, please call Grand Stands, Inc. 800 831-2150